

# STEPS FOR ASSEMBLY, 36" OUTDOOR

**ALL CONTACTING SURFACES REQUIRE FIRE ROCK MORTAR.** Follow the mixing instructions on the mortar bag.

(Numbers in parentheses refer to Part numbers on cover page).

- Set the *Base Plate (2)* on a firm, level foundation, square with the intended viewing area.
- Stack the first course of firebox components, side (4) – back (5) side (4).
- Repeat each course, side (4) – back (5) – side (4) until four courses are complete.
- Check for plumb and level construction of firebox.
- Place two *Smoke Chamber 44 x 6's (9)* along the top of the back wall and across the top of the firebox opening.
- Place a *Large Smoke Chamber Side (11)* across each end of the Smoke Chamber 44 x 6's.
- Place two *Smoke Chamber 38 x 5's (12)* as the second course with *Small Smoke Chamber Sides (15)* at each end.
- Set *Large Chimney Base (17)* atop the completed smoke chamber.
- Stack 4 *Chimney Block (18)* on the Chimney Base.
- Line the firebox with firebrick.

NOTE: The completed Fire Rock product may be built out using concrete blocks and may be veneered with any masonry material. Brick ties may be used between components as well.

\*\*\* Follow all local building codes \*\*\*

